

| AMC                                                                                                                                                               |                                     | ANNEXURE 1<br>Preventive Maintenance Report                                               |               |                        |                |    |         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|-------------------------------------------------------------------------------------------|---------------|------------------------|----------------|---------------------------------------------------------------------------------------|---------|
| Store / Location                                                                                                                                                  |                                     | Caroline Herrera 360                                                                      |               |                        |                | Date / Time 19-4-2025                                                                 |         |
| Completed By                                                                                                                                                      |                                     | A-Team International                                                                      |               |                        |                | Service Type (M/Q/A)                                                                  |         |
| #                                                                                                                                                                 | Check                               | TASK DESCRIPTION                                                                          | Frequency (Q) |                        |                | X                                                                                     | Remarks |
|                                                                                                                                                                   |                                     |                                                                                           | M             | Q                      | A              |                                                                                       |         |
|                                                                                                                                                                   |                                     | AHU / FCU No : (Not Applicable)                                                           |               |                        |                |                                                                                       |         |
| 1                                                                                                                                                                 | <input checked="" type="checkbox"/> | Check for unusual noise                                                                   | X             | X                      | X              |                                                                                       |         |
| 2                                                                                                                                                                 | <input checked="" type="checkbox"/> | Switch off & isolate Power                                                                | X             | X                      | X              |                                                                                       |         |
| 3                                                                                                                                                                 | <input checked="" type="checkbox"/> | Inspect & Clean Condensate Drain tray and connections                                     | X             | X                      | X              |                                                                                       |         |
| 4                                                                                                                                                                 | <input checked="" type="checkbox"/> | Clean air filter and check their condition, recommend replacements as needed              | X             | X                      | X              |                                                                                       |         |
| 5                                                                                                                                                                 | <input checked="" type="checkbox"/> | inspect coil condition, clean as necessary                                                |               | X                      | X              |                                                                                       |         |
| 6                                                                                                                                                                 | <input checked="" type="checkbox"/> | Check actuator valve operation                                                            | X             | X                      | X              |                                                                                       |         |
| 7                                                                                                                                                                 | <input checked="" type="checkbox"/> | Check Chilled water lines condition and insulation                                        |               |                        | X              |                                                                                       |         |
| 8                                                                                                                                                                 | <input checked="" type="checkbox"/> | Inspect all trunking, cabling, wiring, insulation, terminal covers & connections          | X             | X                      | X              |                                                                                       |         |
| 9                                                                                                                                                                 | <input checked="" type="checkbox"/> | Clean Grills & Diffusers as required                                                      |               |                        | X              |                                                                                       |         |
| 10                                                                                                                                                                | <input checked="" type="checkbox"/> | Vent air from cooling coils. Report any significant air locking for further investigation |               | X                      | X              |                                                                                       |         |
| 11                                                                                                                                                                | <input checked="" type="checkbox"/> | Restore power supply and run unit                                                         | X             | X                      | X              |                                                                                       |         |
| 12                                                                                                                                                                | <input checked="" type="checkbox"/> | Check thermostat operation                                                                | X             | X                      | X              |                                                                                       |         |
| 13                                                                                                                                                                | <input checked="" type="checkbox"/> | Check starter/VFD operation                                                               | X             | X                      | X              |                                                                                       |         |
| 14                                                                                                                                                                | <input checked="" type="checkbox"/> | Inspect & clean strainers where fitted                                                    |               |                        | X              |                                                                                       |         |
| 15                                                                                                                                                                | <input checked="" type="checkbox"/> | Check equipment Current                                                                   | X             | X                      | X              |                                                                                       |         |
| 16                                                                                                                                                                | <input checked="" type="checkbox"/> | Check equipment Voltage                                                                   | X             | X                      | X              |                                                                                       |         |
| 17                                                                                                                                                                | <input checked="" type="checkbox"/> | Check Room temperature                                                                    | X             | X                      | X              |                                                                                       |         |
| Electrical (DB/lights) (Not Applicable)                                                                                                                           |                                     |                                                                                           |               |                        |                |                                                                                       |         |
| 1                                                                                                                                                                 | <input type="checkbox"/>            | Check and the clean the DB                                                                |               | X                      | X              |                                                                                       |         |
| 2                                                                                                                                                                 | <input type="checkbox"/>            | Check and tightening o the loose wire if any                                              |               | X                      | X              |                                                                                       |         |
| 3                                                                                                                                                                 | <input type="checkbox"/>            | Check all the breakers for the proper functioning                                         |               | X                      | X              |                                                                                       |         |
| 4                                                                                                                                                                 | <input type="checkbox"/>            | Check all the transformers / ballast for sign of overheating                              |               | X                      | X              |                                                                                       |         |
| 5                                                                                                                                                                 | <input type="checkbox"/>            | Check all the wall power socket for proper functioning                                    |               | X                      | X              |                                                                                       |         |
| Plumbing (Not Applicable)                                                                                                                                         |                                     |                                                                                           |               |                        |                |                                                                                       |         |
| 1                                                                                                                                                                 | <input type="checkbox"/>            | Check water connection for any leakage                                                    |               | X                      | X              |                                                                                       |         |
| 2                                                                                                                                                                 | <input type="checkbox"/>            | Check the sink for any leakage                                                            |               | X                      | X              |                                                                                       |         |
| 3                                                                                                                                                                 | <input type="checkbox"/>            | Check all the plumbing fitting for any leakage                                            |               | X                      | X              |                                                                                       |         |
| Drain Flushing                                                                                                                                                    |                                     |                                                                                           | one<br>Month  | Two<br>Month           | client<br>call | Equipment Notes:                                                                      |         |
| 1                                                                                                                                                                 | <input type="checkbox"/>            | Check the Unit Floor drains and Flush                                                     |               |                        |                |                                                                                       |         |
| 2                                                                                                                                                                 | <input type="checkbox"/>            | Check the Unit Floor Cleanouts and Flush                                                  |               |                        |                |                                                                                       |         |
| General Notes:                                                                                                                                                    |                                     |                                                                                           |               |                        |                |                                                                                       |         |
| Technician Sign :                                                                                                                                                 |                                     |        |               | Client Incharge Sign : |                |  |         |
| HAWALLY-BLOCK 11-STREET 169-BUILDING 13525-SAAD ARBID JALAWI BUILDING- FLOOR 1ST-OFFICE 1<br>WEBSITE: WWW.ATEAMKW.COM EMAIL: CONTACT@ATEAMKW.COM.INFO@ATEAMKW.COM |                                     |                                                                                           |               |                        |                |                                                                                       |         |