



0074

Store / Location : Max Fastuon (Khuran mall) Date : 14-08-2025

Completed By : \_\_\_\_\_ Service Type (M/Q/A) : \_\_\_\_\_

| No.                           | Check                               | TASK DESCRIPTION                                                                          | Frequency (Q) |           |             | X | Remarks |
|-------------------------------|-------------------------------------|-------------------------------------------------------------------------------------------|---------------|-----------|-------------|---|---------|
|                               |                                     |                                                                                           | M             | Q         | A           |   |         |
|                               |                                     | AHU / FCU No : <u>AHU-5 FCU-4</u>                                                         |               |           |             |   |         |
| 1                             | <input checked="" type="checkbox"/> | Check For Unusual Noise                                                                   | X             | X         | X           |   |         |
| 2                             | <input checked="" type="checkbox"/> | Switch Off & Isolate Power                                                                | X             | X         | X           |   |         |
| 3                             | <input checked="" type="checkbox"/> | Inspect & Clean Condensate Drain Tray And Connections                                     | X             | X         | X           |   |         |
| 4                             | <input checked="" type="checkbox"/> | Clean Air Filter And Check Their Condition, Recommend Replacements As Needed              | X             | X         | X           |   |         |
| 5                             | <input checked="" type="checkbox"/> | Inspect Coil Condition, Clean As Necessary                                                |               | X         | X           |   |         |
| 6                             | <input checked="" type="checkbox"/> | Check Actuator Valve Operation                                                            | X             | X         | X           |   |         |
| 7                             | <input type="checkbox"/>            | Check Chilled Water Lines Condition And Insulation                                        |               |           | X           |   |         |
| 8                             | <input checked="" type="checkbox"/> | Inspect All Trunking, Cabling, Wiring, Insulation, Terminal Covers & Connections          | X             | X         | X           |   |         |
| 9                             | <input type="checkbox"/>            | Clean Grills & Diffusers As Required                                                      |               |           | X           |   |         |
| 10                            | <input checked="" type="checkbox"/> | Vent Air From Cooling Coils. Report Any Significant Air Locking For Further Investigation |               | X         | X           |   |         |
| 11                            | <input checked="" type="checkbox"/> | Restore Power Supply And Run Unit                                                         | X             | X         | X           |   |         |
| 12                            | <input checked="" type="checkbox"/> | Check Thermostat Operation                                                                | X             | X         | X           |   |         |
| 13                            | <input checked="" type="checkbox"/> | Check Starter/vfd Operation                                                               | X             | X         | X           |   |         |
| 14                            | <input type="checkbox"/>            | Inspect & Clean Strainers Where Fitted                                                    |               |           | X           |   |         |
| 15                            | <input checked="" type="checkbox"/> | Check Equipment Current                                                                   | X             | X         | X           |   |         |
| 16                            | <input checked="" type="checkbox"/> | Check Equipment Voltage                                                                   | X             | X         | X           |   |         |
| 17                            | <input checked="" type="checkbox"/> | Check Room Temperature                                                                    | X             | X         | X           |   |         |
| <b>Electrical (DB/lights)</b> |                                     |                                                                                           |               |           |             |   |         |
| 1                             | <input type="checkbox"/>            | Check And The Clean The Db                                                                |               | X         | X           |   |         |
| 2                             | <input type="checkbox"/>            | Check And Tightening O The Loose Wire If Any                                              |               | X         | X           |   |         |
| 3                             | <input type="checkbox"/>            | Check All The Breakers For The Proper Functioning                                         |               | X         | X           |   |         |
| 4                             | <input type="checkbox"/>            | Check All The Transformers / Ballast For Sign Of Overheating                              |               | X         | X           |   |         |
| 5                             | <input type="checkbox"/>            | Check All The Wall Power Socket For Proper Functioning                                    |               | X         | X           |   |         |
| <b>Plumbing</b>               |                                     |                                                                                           |               |           |             |   |         |
| 1                             | <input type="checkbox"/>            | Check water connection for any leakage                                                    |               | X         | X           |   |         |
| 2                             | <input type="checkbox"/>            | Check the sink for any leakage                                                            |               | X         | X           |   |         |
| 3                             | <input type="checkbox"/>            | Check all the plumbing fitting for any leakage                                            |               | X         | X           |   |         |
| <b>Drain Flushing</b>         |                                     |                                                                                           |               |           |             |   |         |
|                               |                                     |                                                                                           | One Month     | Two Month | Client Call |   |         |
| 1                             | <input type="checkbox"/>            | Check the Unit Floor drains and Flush                                                     |               |           |             |   |         |
| 2                             | <input type="checkbox"/>            | Check the Unit Floor Cleanouts and Flush                                                  |               |           |             |   |         |

Equipment Notes:

Notes:

Technician Sign : RakusClient Incharge Sign : Asghar

Hawally- Block 11- Street 169 - Building 13525 - Saad Arbid Jalawi Building - Floor 1st - Office 1

Website: www.ateamkw.com - Email: contact@ateamkw.com - info@ateamkw.com