

| AMC                                                                                                                                                                                                       |                                     | ANNEXURE 1<br>Preventive Maintenance Report                                               |                      |                                           |                        | <br><b>A-TEAM</b><br>— آي-تيم — |         |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|-------------------------------------------------------------------------------------------|----------------------|-------------------------------------------|------------------------|--------------------------------------------------------------------------------------------------------------------|---------|
| Store / Location <u>Polo Ralph Lauren</u>                                                                                                                                                                 |                                     |                                                                                           |                      | Date / Time <u>10-08-2024</u>             |                        |                                                                                                                    |         |
| Completed By <u>Rahul</u>                                                                                                                                                                                 |                                     |                                                                                           |                      | Service Type (M/Q/A)                      |                        |                                                                                                                    |         |
| #                                                                                                                                                                                                         | Check                               | TASK DESCRIPTION                                                                          | Frequency (Q)        |                                           |                        | X                                                                                                                  | Remarks |
|                                                                                                                                                                                                           |                                     |                                                                                           | M                    | Q                                         | A                      |                                                                                                                    |         |
|                                                                                                                                                                                                           |                                     | AHU / FCU No :                                                                            |                      |                                           |                        |                                                                                                                    |         |
| 1                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check for unusual noise                                                                   | X                    | X                                         | X                      |                                                                                                                    |         |
| 2                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Switch off & isolate Power                                                                | X                    | X                                         | X                      |                                                                                                                    |         |
| 3                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Inspect & Clean Condensate Drain tray and connections                                     | X                    | X                                         | X                      |                                                                                                                    |         |
| 4                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Clean air filter and check their condition, recommend replacements as needed              | X                    | X                                         | X                      |                                                                                                                    |         |
| 5                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | inspect coil condition, clean as necessary                                                |                      | X                                         | X                      |                                                                                                                    |         |
| 6                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check actuator valve operation                                                            | X                    | X                                         | X                      |                                                                                                                    |         |
| 7                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check Chilled water lines condition and insulation                                        |                      |                                           | X                      |                                                                                                                    |         |
| 8                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Inspect all trunking, cabling, wiring, insulation, terminal covers & connections          | X                    | X                                         | X                      |                                                                                                                    |         |
| 9                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Clean Grills & Diffusers as required                                                      |                      |                                           | X                      |                                                                                                                    |         |
| 10                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Vent air from cooling coils. Report any significant air locking for further investigation |                      | X                                         | X                      |                                                                                                                    |         |
| 11                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Restore power supply and run unit                                                         | X                    | X                                         | X                      |                                                                                                                    |         |
| 12                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Check thermostat operation                                                                | X                    | X                                         | X                      |                                                                                                                    |         |
| 13                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Check starter/VFD operation                                                               | X                    | X                                         | X                      |                                                                                                                    |         |
| 14                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Inspect & clean strainers where fitted                                                    |                      |                                           | X                      |                                                                                                                    |         |
| 15                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Check equipment Current                                                                   | X                    | X                                         | X                      |                                                                                                                    |         |
| 16                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Check equipment Voltage                                                                   | X                    | X                                         | X                      |                                                                                                                    |         |
| 17                                                                                                                                                                                                        | <input checked="" type="checkbox"/> | Check Room temperature                                                                    | X                    | X                                         | X                      |                                                                                                                    |         |
| <b>Electrical (DB/lights)</b>                                                                                                                                                                             |                                     |                                                                                           |                      |                                           |                        |                                                                                                                    |         |
| 1                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check and the clean the DB                                                                |                      | X                                         | X                      |                                                                                                                    |         |
| 2                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check and tightening o the loose wire if any                                              |                      | X                                         | X                      |                                                                                                                    |         |
| 3                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check all the breakers for the proper functioning                                         |                      | X                                         | X                      |                                                                                                                    |         |
| 4                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check all the transformers / ballast for sign of overheating                              |                      | X                                         | X                      |                                                                                                                    |         |
| 5                                                                                                                                                                                                         | <input checked="" type="checkbox"/> | Check all the wall power socket for proper functioning                                    |                      | X                                         | X                      |                                                                                                                    |         |
| <b>Plumbing</b>                                                                                                                                                                                           |                                     |                                                                                           |                      |                                           |                        |                                                                                                                    |         |
| 1                                                                                                                                                                                                         | <input type="checkbox"/>            | Check water connection for any leakage                                                    |                      | X                                         | X                      |                                                                                                                    |         |
| 2                                                                                                                                                                                                         | <input type="checkbox"/>            | Check the sink for any leakage                                                            |                      | X                                         | X                      |                                                                                                                    |         |
| 3                                                                                                                                                                                                         | <input type="checkbox"/>            | Check all the plumbing fitting for any leakage                                            |                      | X                                         | X                      |                                                                                                                    |         |
| <b>Drain Flushing (Not Applicable)</b>                                                                                                                                                                    |                                     |                                                                                           | <b>one<br/>Month</b> | <b>Two<br/>Month</b>                      | <b>client<br/>call</b> | Equipment Notes:                                                                                                   |         |
| 1                                                                                                                                                                                                         | <input type="checkbox"/>            | Check the Unit Floor drains and Flush                                                     |                      |                                           |                        |                                                                                                                    |         |
| 2                                                                                                                                                                                                         | <input type="checkbox"/>            | Check the Unit Floor Cleanouts and Flush                                                  |                      |                                           |                        |                                                                                                                    |         |
| <b>General Notes:</b>                                                                                                                                                                                     |                                     |                                                                                           |                      |                                           |                        |                                                                                                                    |         |
| Technician Sign : <u>Rahul</u>                                                                                                                                                                            |                                     |                                                                                           |                      | Client Incharge Sign : <u>[Signature]</u> |                        |                                                                                                                    |         |
| المهبولة - قطعة ١ - مبنى ١٩٣٠١ - شارع ١٤٣ - مبنى صالح عبد الغني المطوع دور ١م - مكتب ١٧<br>Mahboula - Block 1 - Building 19301 - Street 143 - Saleh Abdul-Ghani Al-Mutawa Building - Floor 1m - Office 17 |                                     |                                                                                           |                      |                                           |                        |                                                                                                                    |         |